





MacBook Pro 17" Unibody Left Speaker Assembly Replacement

Written By: Andrew Bookholt





Step 1 — Left Speaker Assembly



- Remove the two 7.9 mm Phillips screws securing the left speaker assembly to the logic board.

Step 2



- Slightly lift the left speaker assembly off the logic board.
- Use the flat end of a spudger to lift the microphone and left speaker connectors out of their sockets on the logic board.
- ⓘ Pry up from beneath the wires.
- Remove the left speaker assembly from the logic board.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-07 07:26:28 AM.